

LEHNER



VINERO®

Operating instructions with parts list

Control LAS 3
Software from version 2.0
Status: June 2009

Serial number:

Software version:

Table of Contents

1	What you should know.....	4
1.1	Foreword.....	4
1.2	Notes on these operating instructions.....	4
1.3	Intended use	5
1.4	Warranty.....	5
1.5	About your safety	6
1.6	Identification.....	6
2	Starting up the VINERO®	7
2.1	Mounting the frame	7
2.2	Electrical connection	7
2.3	Mounting the VINERO®	8
2.4	Attaching the control panel	8
3	Operating the VINERO®	9
3.1	Controls on the control panel	9
3.2	The display.....	10
3.3	Switching on / off.....	11
3.4	Setting the speed	13
3.5	Setting the slide opening.....	13
3.6	Opening/closing the slide	14
3.7	Performing the slide reference run.....	15
3.8	Setting the working width (special accessory)	16
3.9	Setting the lateral distribution (special accessory).....	16
3.10	Empty signal indicator.....	17

Table of Contents

4 Settings and displays	18
4.1 Making settings	18
4.2 Language	18
4.3 Selecting the empty indicator	19
4.4 Setting signal for electronic lifting gear control (EHR).....	19
4.5 Setting cycle for electronic lifting gear control (EHR) (special equipment for headland manager).....	20
4.6 Adjusting the empty indicator	20
4.7 Displaying the spreader type.....	21
4.8 Checks	21
4.9 Spreading width and turning procedure	22
5 Special accessories.....	23
5.1 Attach standard rail	23
5.2 Attach Vario rail	23
5.3 Headland manager.....	24
6 Maintenance and cleaning	26
6.1 Service	26
6.2 Cleaning	26
7 Appendix	27
7.1 EU Declaration of Conformity.....	27
7.2 Distribution box reference list.....	28
7.3 List of spare parts.....	29
7.4 Troubleshooting.....	33
7.5 Spreading charts	34
7.6 Slide settings	43

1 What you should know

1.1 Foreword

Thank you for placing your trust in us. We congratulate you on your decision. With the VINERO®, you have acquired a high-quality and innovative product.

Thanks to its advanced design, meticulous material selection, state-of-the art manufacturing techniques and the precision work of our employees, this equipment meets all efficiency, quality, reliability and value requirements.

Care and maintenance in accordance with the operating instructions ensures safe operation and maintains the value of your VINERO®.

1.2 Notes on these operating instructions

These operating instructions are a part of the VINERO® and must always be readily available. All persons who work with the VINERO® must read and follow the operating instructions.

They will learn about the technical details and how to control the machine and optimise its performance.

Warning notices

Warning notices in these operating instructions are identified as follows:

	Danger! Warning against immediate danger. Non-observance of appropriate measures may result in death and severe personal injury or serious damage to property..
	Warning! Warning of possible danger. Death, severe personal injury or serious damage to property are possible.
	Caution! Warning of possible dangerous situations. Slight personal injury or damage to property is possible.

1 What you should know

1.3 Intended use

The VINERO® is used exclusively for spreading fertilizer and seeds.

1.4 Warranty

We provide a guarantee of 6 months and warranty of 24 months on the VINERO®.

	Caution! Defective plugs and cables or those of the wrong size can lead to functional deficiencies. Use original or cables and plugs approved by the manufacturer only.
---	--

Any changes to cable or plug connections without factory approval automatically invalidates the warranty. Motors may not be opened or dismantled.

Warranty repairs must be coordinated with the manufacturer before any work is started.

For replacement parts, additional expenses are automatically charged for any changes made to cables and plugs by the customer. Replacement parts are to be returned carriage paid.

Rusted bearings are not subject to the manufacturer's warranty.

Prior to assembly:

Check your VINERO® upon receipt for any damage caused in transit. Any such damage must be reported to the manufacturer within 24 hours of receipt.

1 What you should know

1.5 About your safety

- Carefully read and observe these operating instructions before use. Always keep these instructions at the point of use.
- Observe the accident prevention regulations, safety and operating regulations and the regulations for environmental protection.
- Observe all applicable standards and guidelines.
- When travelling on public roads and streets, observe the road traffic regulations.
- Observe the safety instructions.
- Immediately resolve any safety-related deficiencies.
- Keep out of the spreading zone. Make sure that no other persons are in the spreading zone.
- Do not touch the hopper during operation.
- Follow the safety guidelines of the package insert when spreading granulates.
- Do not undertake any repairs, maintenance or cleaning procedures on the VINERO® when the mains plug is connected.

1.6 Identification

The serial number of the spreader is located on the back of the framework.

Note the serial number in these operating instructions so that it is readily available for inquiries.

The hardware and software versions are briefly displayed when the control panel is connected.

Make a note of the software version in these operating instructions so that it is readily available for inquiries.

**LEHNER GmbH
LAS3 V2.0**

2 Starting up the VINERO®

2.1 Mounting the frame

The VINERO® can be screwed on directly or an auxiliary bracket used. Mounting holes have been provided on the back of the frame.

The recommended delivery height is approx. 0.2 m. Please refer to the spreading charts for precise details.

The VINERO® can be mounted at the front or back of the tractor. It can be fitted to tractors, all-terrain vehicles or cultivation machines. Because a full hopper makes the VINERO® considerably heavier, the load capacity of platform gates and other consoles is to be checked.

2.2 Electrical connection

Technical data

Operating voltage	10 to 15 volts
Fuse	25 A
Motor output	12 watts
Speed range	40 to 66 rpm
Power consumption of gear motor	0.4 - 1 A
Operating temperature	-10 to +70 °C
Storage temperature	-30 to +70 °C

Any changes to cable or plug connections without factory approval automatically invalidates the entire warranty. Changes to cables are taken into account in the case of repair.

You must consult with the manufacturer before carrying out any cable modifications.

Power loss must be taken into account when extending cables. A poor power supply may prevent you from achieving the desired speed. A poor power supply can momentarily cause the spreader to fail completely.

2 Starting up the VINERO®

2.3 Mounting the VINERO®


Check whether the hopper fits well in the hopper platform. Check that the VINERO® is securely attached.

2.4 Attaching the control panel



Caution, risk of short circuits!

Ensure that the cable is not routed over any sharp edges.



Mount support for the control panel in the vehicle cabin.

Plug the control panel cable into the 3-pin plug **1 of the carrier vehicle**.
If the plug is not available, use the provided battery cable:

Connect terminal **2** to -pin of the battery
(not to the body).


Connect terminal **3** (with fuse **4**) to +pin of the battery
Place cable end with socket in carrier vehicle.

Plug the spreader cable into the 16-pin plug of the control panel.
The battery cable supplied must be used to ensure an optimum power supply.

Your device is now ready to operate.

3 Operating the VINERO®


3.1 Controls on the control panel



- 1 Switching on / off
- 2 Display
- 3 Opening and closing the slide
Slide open: green LED lights up
Slide closed: yellow LED lights up
- 4 Setting the speed or slide
- 5 Switch to change between speed and slide
- 6 Empty indicator

3 Operating the VINERO®

3.2 The display



1 Arrow denotes the active line

2 Agitator speed

3 Slide opening

4 OK sign for open slide

Error messages, also see Troubleshooting chapter.

3 Operating the VINERO®

3.3 Switching on / off



Press the button.

The speed of the agitator and the slide opening is displayed. The slide is always closed when switching on the drive motor.

> Speed 60
Slide 29



Press the button.

The slide is opened, the green LED lights up.

The drive motor starts.

> Speed 60
Slide 29 ok

If this message is displayed, a cable is damaged or a plug disconnected.

> Speed 60
Connecting spr.

Low temperatures can cause the empty indicator to respond slowly.
To check the adjustment:

Allow the spreader to run for approx. 1 minute with the slide closed.

If the slide is then opened, the empty indicator must be activated after approx. 5 seconds.

If this doesn't happen, move the empty indicator 5% into the negative range; see Settings and displays chapter, Adjusting the empty indicator.

3 Operating the VINERO®

Autostart

If the motor is difficult to start due to heavy loads, start the motor up to 10 times in alternating motor direction. If the mixer does not break free as a result, the motor is automatically switched off.

The following message is displayed:

Agitator blocked
Slide 29



Danger!

Never open the hopper or touch the spreading disc when the drive motor is running.

Switch off the drive motor and ensure that the motor is stopped before opening the hopper or touching the agitator.

To eliminate the blockage:

Switch off the machine.

Empty hopper and check for foreign bodies.


Check power supply.

3 Operating the VINERO®

3.4 Setting the speed



If necessary, press the button to select the speed; the arrow points to the first line in the display.




Press the button to set the speed.
The speed can be adjusted continuously from 40 - 66 rpm.
The optimum speed is 66 rpm.
The setpoint speed is displayed for 10 seconds, after which the actual speed is displayed.

> Speed	60
Slide	29

3.5 Setting the slide opening



If necessary, press the button to select the slide. The arrow points to the second line in the display.



Press the button to adjust the slide opening.
You can take the required slide opening from the spreading chart.

Speed	60
> Slide	29

3 Operating the VINERO®

3.6 Opening/closing the slide



Danger!

The drive motor starts immediately when switched on.
Make sure the danger area is clear when starting.



Press the button to open or close the slide.
Slide open: green LED lights up
Slide closed: yellow LED lights up

> Speed 60
Slide 29 ok

Slide monitoring


If the slide does not reach the specified position within 10 seconds, the spreader switches off.

The following message is shown in the display:

Slide not open or Slide not closed. 5 warning signals also sound. For troubleshooting, see Troubleshooting chapter.

Manual adjustment

The number of hoses to be used can be selected by manually setting the slider. The number depends on the slide; see Slide Settings.




Lever in position **A** for all hoses.
Lever in position **B** for some of the hoses.

3 Operating the VINERO®

3.7 Performing the slide reference run

The slide motor and control panel are adjusted to match each other at the factory. The setting can be lost in the course of time or when replacing the control panel.



Switch off the machine.

Press and hold the button for switching between speed and slide and the + button to switch the machine on.

The slide performs its reference run.

Approx. 240 is displayed as the upper value and approx. 40 as the lower value; in the second line the message **OK** is displayed.

Switch machine off at ON/OFF switch so that the values are stored.


If a slide reference run cannot be performed, the following message flashes on the display: **slide not calib.**

Check the mechanical clearance of the slide, the cable and the connectors. Then perform the reference run again.

3 Operating the VINERO®

3.8 Setting the working width (special accessory)


The Vario-rail can be set to a working width of between 0.8 and 1.6 m.



Undo screws (arrowed) and set distributor rails to the desired width.

3.9 Setting the lateral distribution (special accessory)


For wide area output all hoses are positioned vertically on the Vario-rail:



3 Operating the VINERO®

For fertilising rows, the hoses on the Vario-rail are positioned at an angle. The inner hoses can each be positioned next to an outer hose.

6-hose version:



3-hose version:



3.10 Empty signal indicator

The empty indicator shows you when the spreading material in the hopper falls below a specific fill level:

The following message flashes on the display for approx. 5 seconds:
Hopper empty, 8 warning signals sound and the red LED flashes on the empty indicator.

To switch off the empty signal:

Close the slide or switch off the spreader.

4 Settings and displays

The operating panel can be used to make the following settings:

Language

Empty warning

EHR signal


EHR cycle (special equipment for headland manager)

Empty warning adjustment

Control type

4.1 Making settings

Switch off the machine.




Press both buttons at the same time to switch on the machine.

The language selection is displayed.



Press the button to select the desired menu item.

4.2 Language



Press the button to set the language.



Press toggle switch: Setting saved, next menu item
or

press main switch: Setting saved and machine switched off.

4 Settings and displays

4.3 Selecting the empty indicator



Press the button to select the empty indicator.

Via agitator motor (1) with soft agitator,
via external empty indicator (2) - not
programmed
or
empty indicator switched off (0)

Empty ind. 1
One agitator



Press toggle switch: Setting saved, next
menu item
or
press main switch: Setting saved and
machine switched off.

4.4 Setting signal for electronic lifting gear control (EHR)

When the spreader is equipped with the headland manager accessory, the hydraulic signal of the tractor can be detected. The signal is emitted when lifting or lowering.

The spreader is set at the factory for the signal when lifting.

If the tractor emits the hydraulic signal when lowering, you can adjust the spreader.



Press the button to set the EHR signal.
EHR signal for lifting:
High active is displayed.
EHR signal for lowering:
Low active is displayed.

EHR signal 0
High active



Press toggle switch: Setting saved, next
menu item
or
press main switch: Setting saved and
machine switched off.

4 Settings and displays

4.5 Setting cycle for electronic lifting gear control (EHR) (special equipment for headland manager)

If the spreader is equipped with the headland manager accessory, a specific cycle can be set for opening the slide.



Press button to select the EHR cycle between 1 and 10.

EHR cycle 4



Press toggle switch: Setting saved, next menu item
or
press main switch: Setting saved and machine switched off.

4.6 Adjusting the empty indicator

Depending on the requirement and spreading material, the empty indicator can be set to respond earlier or later.

The value for the empty indicator to switch on (if the spreading material falls below a certain fill level) can be adjusted from -50 to +50.

Note:

Depending on the spreading material or material humidity, the remainder level may vary somewhat.



Press the button to set the respective value.

Factory setting is 0

With + values, the empty indicator responds at a higher fill level.

With - values, the empty indicator responds at a lower fill level.

Setting 0
Empty ind. ON

4 Settings and displays



Press toggle switch: Setting saved, next menu item
or
press main switch: Setting saved and machine switched off.

4.7 Displaying the spreader type

The control is provided for a variety of spreaders.
The VINERO® is programmed at the factory.




Press toggle switch: Setting saved, next menu item
or
press main switch: Setting saved and machine switched off.

Spread. type 0
VINERO

4.8 Checks

Voltage check

In order to check the operating voltage (in V), the spreader must be on and the hopper filled.



Press the button for 5 seconds.
The operating voltage is displayed for 8 seconds.

Voltage 14.0 V

Performance check

The motor is set at the factory. No changes are permitted, since otherwise the drive and control parameters no longer match.

To check the performance data, the spreader must be on.

4 Settings and displays



Press the button for min. 5 seconds.
The following information is displayed as long as the button is pressed:

TLP 23.4 W 2800
91R 3.4V 1.0A

Line 1: current drive motor, power consumption in watts and the exact speed.

Line 2: R value for factory-internal data, the motor voltage in volts, the current consumption of the motor in amps.

4.9 Spreading width and turning procedure

Please note when turning that the turning quantities may differ from the quantities when using the device, as there may be vibrations.

Calculation according to the following formula

$$\frac{\text{kg/min} \times 600}{\text{Speed} \times \text{spreading width (m)}} = \text{Output (kg/ha)}$$

$$\frac{\text{kg/min} \times 600}{\text{Output/ha (kg)} \times \text{spreading width (m)}} = \text{Speed (km/h)}$$


$$\frac{\text{Speed (km/h)} \times \text{output /ha (kg)} \times \text{spreading width (m)}}{600} = \text{kg/min}$$

5 Special accessories

5.1 Attach standard rail

The standard rail is mounted directly onto the carrier vehicle. The hoses can be connected independently of the numbering.

5.2 Attach Vario rail



Mount the rails **1** on the frame **2**

Mount distribution rail **3** on bars **1**, paying attention to mounting direction (arrowed).

Mount distributor rails **4** on distributor rail **3**.


Mount distributor rails **5** with 4 rubber buffers **6** onto distributor rail **3**.

Connect the hoses of the distributor rail to the spreader, paying attention to the numbering.

5 Special accessories

5.3 Headland manager

When lowering the hydraulics, the slide must be opened manually the first time.



Press the button.
The slide is opened, the green LED lights up.
If the headline manager is connected,
an * is displayed at the end of the first line.

Speed	66*
Slide	29

With the headline manager, the slide is automatically opened when lowering the hydraulic and automatically closed when lifting.
The slide can **be manually** opened and closed from the control panel.

The signal can be detected by means of a 7-pin plug or a sensor signal.

7-pin plug



1. Connect the connecting cable of the control panel to the 7-pin signal plug of the tractor.
2. Set the EHR signal of the spreader depending on whether the tractor emits the hydraulic signal when lifting or lowering.

5 Special accessories

Sensor signal



1. Mount the sensor in the joint section of the lower link.
2. Mount the magnetic encoder to the lower link.
3. Set position position of sensor and magnetic encoder.
noting that the switching area of the sensor is at the side.
Maximum spacing 10 mm.

Hydraulics at bottom:

sensor not in range of magnetic sensor.

Hydraulics at top:

sensor must be in field of magnetic encoder.


When raising the hydraulics, the sensor must not exit the magnetic sensor range because otherwise the slide will opened again.

6 Maintenance and cleaning

6.1 Service

The dosing device and slide should be inspected and cleaned from time to time.

In particular, spreading material with a high dust content can cause the slide unit to clog.



1. Remove screws **1** on the right and left.
2. Remove the hopper **2**.
3. Remove four screwws at the side.
4. Remove the cover plate **5**.
5. Undo screw **6** and remove agitator **4**.
6. Remove nuts **3**.
7. Dismantle the hopper platform and remove flow plates.
8. Clean the slide unit with a broom or compressed air.
For corrosive spreading material, regularly remove and clean the motor, and fill the shaft end with grease or copper compound.


6.2 Cleaning

The hopper can be almost fully emptied by means of the residual discharge.

1. Unscrew hopper.
2. Clean spreader and hopper with a broom.


7 Appendix

7.1 EU Declaration of Conformity

 The image shows the CE mark (European Conformity) and the VDE EMV logo. The CE mark is a large, bold, black 'C' and 'E' symbol. Below it is the VDE EMV logo, which consists of a circular emblem with a stylized 'f' or 'E' shape inside, surrounded by the word 'VDE' at the top and 'EMV' at the bottom.	<p>We,</p> <p>LEHNER Agrar GmbH Häuslesäcker 5-9 D-89198 Westerstetten Tel.: (+49) 07348 95 96 - 0 Fax: (+49) 07348 95 96 - 40 www.lehner.eu info@lehner.eu</p> <p>declare that the 12 volt spreader VINERO® conforms to the following directives:</p> <p>Machinery Directive 98/37/EC, Low Voltage Directive 73/23/EEC, EMC Directive 89/336/EEC, EC Directive 93/68/EEC, as well as other relevant EC directives.</p> <p>Westerstetten, 01.03.2007</p> <p><i>H. Lehner</i></p>
--	---

7 Appendix

7.2 Distribution box reference list




Key

Steuerkabel	Control cable	Zuleitung Bedienteil	Control panel supply line	gelb	yellow	grau	grey
Verteilerdose	Junction box	Batteriekabel	Battery cable	rot	red	blau	blue
Motor Streuteller	Spreading disc motor	weiss	white	rosa	pink		
Motor Rührwerk	Mixer motor	braun	brown	schwarz	black		
Schiebermotor	Slide motor	grün	green	violett	violet		

7 Appendix

7.3 List of spare parts




7 Appendix

VINERO® parts list

Designation	Quantity	Material	Size
1 Hopper	1	Plastic	70/100/170 ltr.
2 Sealing cap	1	Plastic	
3 Discharge cover	1	Plastic	
4 Edge guard with padding for hopper	1	Plastic	
5 Cover plate	1	VA	
6 Edge guard with padding	1	Plastic	
7 Steel frame	1	VA	
8 Front plate	1	VA	
9 Hopper bracket	1	VA	100/170 ltr.
10 Knurled screw	4	Plastic / VA	M 8/15
11 Chain guide	1	Plastic	
12 Ball joint head	1	Plastic	Left thread
13 Rubber grommet	1	Plastic	
14 Adjuster slide guide	1	VA	
15 Plastic clamp	1	Plastic	
16 Control cable with plug	1		6/11 meters
17 Distributor box	1	Plastic	
18 Pushrod	1	VA	
19 Chain motor	1		
20 Control panel	1		
21 Upper part of bracket	1	Steel	
22 Lower part of bracket		Steel	

7 Appendix



7 Appendix

Parts list for VINERO® slide unit

Designation	Quantity	Material	Size
1 Hopper seal	1	Rubber	140
2 Hopper platform	1	plastic	150/150/15
3 Agitator	1	VA	
4 Guide bush for slide	1	Plastic	
5 Dosing plate	1	VA	2 mm
6 Adjuster slide	1	VA	2 mm
7 Slide guide	2	VA	2.5 mm
8 Dosing slide	1	VA	2 mm
9 Base plate	1	VA	4 mm
10 Tube plate	1	Plastic	
11 Drive motor	1		

7 Appendix

7.4 Troubleshooting

Troubleshooting LEHNER VINEIRO		Status: 07/2008
Problem	Cause	Solution
No display	Polarity reversed or fuse has blown	Check connections and fuses
Mixer does not turn over	Foreign bodies in the agitator	Empty hopper and check for foreign bodies
Agitator does not turn over	Power supply failed or too weak	Check power supply
Slide not calib.	Reference run could not be performed	Query diagnosis at factory
Spreading disc does not reach set speed	Foreign body on the agitator, load too great or power supply too weak	Check agitator, agitator paddle see Section 3.7 Check power supply
Slide jams	Spreading material or dirt is jammed between the slide plates	Clean slide
On the display: Agitator blocked	Agitator does not turn; switched off after 10 attempts Material may be compacted or blocked by foreign bodies	Check agitator and, if necessary, try starting again
On the display: Slide not open	Slide could not go into position when opening	Check slide for contamination, or perform reference run; see section: Reference run for slide, Cable not plugged in, motor defective
On the display: Slide not closed	Slide could not go into position when closing	Check slide for contamination, or perform reference run; see section: Reference run for slide
The version is displayed again and again.	Fuse oxidised, loose contact,	Check contacts and fuses
Slide does not open although no error message is displayed.	Mechanical damage to slide mechanism	Check slide motor and transfer mechanism
On the display: Connecting spr.	Control panel plug not connected to spreader or cable damaged	Check plug connections and lines
Empty indicator does not respond	Empty indicator is set too low	Adjust empty signal (see Section 4.6)
Headland manager closes the slide when lowering hydraulics and opens when lifting	Signal incorrectly applied	Turn signal. See EHR signal
Headline manager does not always close	Distance to magnetic sensor too great	Check distance, max. 10 mm.

7 Appendix

7.5 Spreading charts

Red clover		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!															
Time open:		Hose number															
	Slide	g/min		Ø overall		1	2	3	4	5	6	7	8	9	10	11	12
V 1	20	318,4	Ø per hose	3821	355	385	371	345	348	296	270	281	286	311	267	292	
V 2				335	386	372	344	371	313	281	287	293	310	262	280		
V 1	19	278,2		296	341	328	308	306	264	230	243	250	273	222	245		
V 2				306	343	336	324	299	269	236	249	256	274	229	250		
V 1	18	245,1		2942	255	305	289	276	263	237	192	218	225	237	184	209	
V 2				265	309	301	283	285	247	203	223	232	246	188	211		
V 1	17	209,9		2519	219	270	260	246	241	207	167	190	194	206	147	168	
V 2				223	271	263	247	239	204	164	187	192	208	148	176		
V 1	16	165,0		1980	175	233	222	201	179	156	117	147	156	171	108	132	
V 2				168	222	215	200	180	159	122	149	153	165	104	126		
V 1	15	129,3		1552	117	189	179	167	146	122	90	118	122	132	68	82	
V 2				127	191	185	168	146	122	88	119	125	137	74	90		
V 1	14	86,4		1037	95	166	153	139	108	89	59	94	98	108	50	64	
V 2				55	121	110	100	68	57	37	70	76	88	31	37		
V 1	13	71,3		855	62	134	121	104	66	53	30	62	67	84	29	40	
V 2				62	135	125	106	65	53	31	62	64	83	30	42		
V 1	12	45,5		546	33	105	94	82	37	28	18	33	38	53	15	19	
V 2				29	103	90	80	40	30	14	34	37	51	12	17		
V 1	11	23,0		276	8	71	61	48	15	11	6	10	11	21	4	6	
V 2				12	73	62	47	16	9	6	10	10	24	4	7		
V 1	10	8,3		100	2	36	28	15	4	1	1	1	3	1	1		
V 2				6	39	31	15	2	1	1	1	5	1	3			
V 1 = 1st attempt																	
V 2 = 2nd attempt																	
Check settings with field samples.																	
© LEHNER																	

7 Appendix

White clover		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!														
Time open:		g/min	g/min	Ø overall	1	2	3	4	5	6	7	8	9	10	11	12
V 1	20	354,3	4251	369	423	411	386	373	339	311	318	319	352	302	323	
V 2				364	429	415	390	379	346	322	326	320	360	302	323	
V 1	19	310,0	3720	326	377	363	336	322	292	262	274	279	310	264	282	
V 2				319	380	371	346	335	304	282	277	271	262	283		
V 1	18	270,4	3245	292	342	328	303	289	260	228	238	248	270	223	246	
V 2				284	335	323	303	284	256	227	238	235	273	223	242	
V 1	17	237,4	2849	255	295	291	268	249	223	195	208	223	241	188	211	
V 2				253	305	289	268	253	226	195	206	220	241	189	206	
V 1	16	195,5	2346	210	259	244	228	195	174	152	173	183	199	154	174	
V 2				208	261	248	228	195	176	152	173	183	199	150	173	
V 1	15	153,6	1844	110	225	209	111	165	148	124	141	150	168	114	131	
V 2				167	222	209	185	154	134	115	140	148	163	118	136	
V 1	14	124,8	1498	124	190	179	94	132	117	95	112	123	132	86	101	
V 2				124	192	183	91	135	119	98	115	123	140	88	102	
V 1	13	100,7	1208	92	159	148	136	98	83	69	87	93	107	59	72	
V 2				92	161	151	135	102	85	69	88	92	107	59	72	
V 1	12	71,3	856	55	131	119	107	67	53	39	60	66	79	33	44	
V 2				58	133	122	105	68	55	40	60	65	79	32	42	
V 1	11	39,7	477	28	97	88	73	37	24	14	23	30	47	9	17	
V 2				28	98	85	54	32	22	14	27	29	47	11	19	
V 1	10	17,8	214	10	68	58	37	9	4	3	2	2	16	1	4	
V 2				7	66	56	39	11	6	1	7	2	16	1	2	
V 1 =	1st attempt															
V 2 =	2nd attempt															
Check settings with field samples.																
															© LEHNER	

7 Appendix

Phacelia		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!													
Time open:		g/min		g/min		Hose number									
	Slide	Ø per hose	Ø overall	1	2	3	4	5	6	7	8	9	10	11	12
V 1	38	510,8	6130	543	558	274	553	378	548	540	542	555	562	536	523
V 2				539	555	253	558	433	547	542	538	562	554	538	528
V 1	36	496,8	5962	540	549	164	549	397	552	542	537	555	546	535	528
V 2				544	551	185	536	416	548	537	540	560	546	544	520
V 1	34	482,8	5793	537	538	123	536	383	537	537	518	544	545	531	505
V 2				531	539	135	529	553	538	363	514	538	511	504	497
V 1	32	489,3	5872	437	525	517	485	512	493	483	465	490	510	475	485
V 2				481	521	514	490	518	501	491	464	494	520	418	455
V 1	30	391,0	4693	416	469	452	408	432	411	394	338	382	426	206	353
V 2				509	470	450	391	426	400	386	313	383	414	192	364
V 1	28	306,6	3679	331	409	351	319	343	329	306	241	280	332	147	275
V 2				326	408	365	328	341	340	310	247	291	335	144	260
V 1	26	230,7	2768	180	279	277	270	287	272	205	216	228	240	156	160
V 2				189	285	280	267	279	257	206	207	212	227	181	176
V 1	24	170,4	2045	168	230	220	197	202	193	177	146	165	181	129	134
V 2				141	205	203	190	170	182	168	143	153	164	108	120
V 1	22	113,8	1366	84	166	160	140	124	125	97	94	97	117	67	82
V 2				79	166	164	137	130	137	104	94	100	116	71	81
V 1	20	84,5	1014	59	130	122	109	91	100	74	73	75	86	48	55
V 2				58	130	120	102	107	94	76	64	73	82	46	54
V 1	18	38,4	461	25	67	59	44	43	38	31	29	37	42	16	20
V 2				27	69	60	51	48	36	29	35	35	44	15	21
V 1	16	31,3	376	22	62	59	50	32	22	17	26	33	38	14	18
V 2				17	52	50	45	33	23	22	25	32	34	11	14
V 1	14	11,9	143	8	39	34	33	13	8	7	13	2	16	4	6
V 2				5	20	18	17	7	4	3	8	9	6	2	3
V 1 = 1st attempt															
V 2 = 2nd attempt															
Check settings with field samples.														© LEHNER	

7 Appendix

Fodder radish		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!																																
Time open:		g/min	g/min	Ø overall	Ø per hose	1	2	3	4	5	6	7	8	9	10	11	12																	
V 1	38	830,7	9969	816	843	874	854	837	840	842	814	818	810	808	818																			
V 2			728	850	870	862	857	848	852	818	835	807	811	825																				
V 1	36	818,6	9824	836	853	833	840	833	824	800	802	798	790	804																				
V 2			802	834	862	848	841	836	828	789	803	797	794	795																				
V 1	34	758,7	9105	768	793	789	755	799	780	737	728	741	747	722	736																			
V 2			769	803	801	770	792	762	766	732	739	744	744	724	712																			
V 1	32	656,4	7877	694	730	709	653	696	656	610	609	645	647	637	617																			
V 2			692	725	708	640	697	624	597	596	631	654	634	652																				
V 1	30	529,3	6352	586	637	588	548	525	488	486	426	511	563	519	547																			
V 2			575	621	424	562	573	515	516	414	508	514	523	545																				
V 1	28	421,8	5062	489	547	133	447	504	448	434	339	426	449	403	448																			
V 2			474	536	381	454	480	344	422	364	380	395	395	431																				
V 1	26	330,5	3966	392	417	366	361	385	340	316	243	296	320	287	319																			
V 2			373	441	396	342	363	327	308	254	235	339	277	235																				
V 1	24	226,6	2720	248	311	271	230	291	258	266	124	196	221	166	203																			
V 2			248	290	284	240	280	198	215	139	166	223	169	202																				
V 1	22	134,6	1616	123	124	109	134	120	104	67	101	116	80	98																				
V 2			169	216	227	160	218	158	140	81	110	161	104	141																				
V 1	20	93,6	1123	102	169	123	97	124	93	72	44	59	88	60	78																			
V 2			100	170	114	96	135	90	74	56	65	94	64	79																				
V 1	18	48,7	585	47	93	71	53	67	46	38	21	26	43	31	35																			
V 2			57	97	82	34	66	54	38	25	24	48	35	38																				
V 1	16	20,5	246	24	50	49	10	23	7	18	7	8	25	9	20																			
V 2			27	56	38	25	12	5	7	11	9	24	7	21																				
V 1	14	6,7	80	6	7	14	2	3	2	3	1	13	6	27	5																			
V 2			11	21	6	5	3	2	2	1	2	3	5	10																				
V 1 =	1st attempt																																	
V 2 =	2nd attempt																																	
check settings with field samples.																																		
© LEHNER																																		

7 Appendix

KAS		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!																															
Time open:		g/min		g/min		Ø per hose		Ø overall		1		2		3		4		5		6		7		8		9		10		11		12	
	Slide																																
V 1	38		1545,4		18345		1473		1530		1646		1632		1642		1588		1550		1560		1552		1520		1470		1474				
V 2							1478		1528		1674		1626		1638		1532		1502		1514		1526		1498		1472		1464				
V 1	36		1503,3		18040		1458		1364		1630		1600		1640		1510		1464		1468		1508		1572		1420		1384				
V 2							1460		1520		1646		1594		1622		1478		1436		1458		1494		1466		1430		1458				
V 1	34		1409,3		16911		1388		1484		1540		1440		1548		1376		1334		1368		1376		1380		1380		1396				
V 2							1372		1448		1436		1446		1504		1406		1322		1364		1408		1350		1364		1392				
V 1	32		1143,1		13717		1220		1186		1232		1116		1286		1202		1112		1156		1162		1218		1190		1228				
V 2							1160		1052		1004		884		1100		1134		1082		1078		1128		1138		1152		1214				
V 1	30		847,8		10174		962		704		598		615		844		922		882		817		1042		1046		1046		830				
V 2							1016		770		622		384		902		916		733		875		958		922		954		988				
V 1	28		552,0		6624		718		487		419		385		616		682		458		535		216		668		666		729				
V 2							614		487		348		362		401		730		505		550		652		588		693		739				
V 1	26		341,9		4103		476		252		263		197		480		464		311		259		407		292		436		431				
V 2							438		308		267		262		402		433		237		88		437		315		368		353				
V 1	24		177,5		2130		341		64		94		133		288		192		189		132		113		185		149		326				
V 2							267		51		93		145		257		143		244		95		64		227		227		241				
V 1	22		78,9		947		150		26		33		41		60		127		46		7		11		79		135		155				
V 2							113		90		37		22		124		148		81		50		18		96		80		164				
V 1	20		16,6		199		28		5		22		1		10		25		24		4		5		0		41		36				
V 2							30		11		5		0		36		24		7		6		4		32		31						
V 1	18		5,0		60		15		5		0		2		4		5		6		4		6		0		11		9				
V 2							14		12		1		1		0		4		8		3		0		0		5		5				
V 1 =	1st attempt																																
V 2 =	2nd attempt																																
Check settings with field samples.																																	
© LEHNER																																	

7 Appendix

White mustard		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!														
Time open:		g/min	Ø per hose	Ø overall	1	2	3	4	5	6	7	8	9	10	11	12
V 1	38	1041.8	12501	1046	1068	1068	1076	1044	1048	1020	1046	1040	1020	1018		
V 2			1016	1048	1062	1060	1084	1064	1036	1016	1034	1038	1008	1010		
V 1	36	1000.9	12011	1016	1034	1056	1040	1046	1024	1018	935	972	968	966	981	
V 2			1016	1028	1050	1022	1054	1028	978	938	954	970	962	966		
V 1	34	882.1	10586	946	938	909	816	883	917	867	848	849	887	866	852	
V 2			944	938	910	814	922	901	852	849	858	895	872	838		
V 1	32	790.3	9484	827	846	835	775	862	835	739	726	745	815	746	765	
V 2			820	842	833	782	809	804	736	711	755	816	773	771		
V 1	30	635.4	7625	682	731	702	632	742	660	599	519	531	633	604	612	
V 2			680	723	713	631	718	636	579	512	567	629	605	609		
V 1	28	528.7	6344	565	618	574	532	618	528	444	474	486	517	490	492	
V 2			549	604	592	534	594	512	502	474	481	528	488	492		
V 1	26	418.2	5019	444	506	464	434	502	410	386	328	357	442	372	388	
V 2			448	483	455	413	488	403	396	368	370	419	374	387		
V 1	24	317.8	3813	350	369	459	331	402	312	271	248	264	324	262	279	
V 2			354	398	348	322	402	320	280	226	252	292	267	288		
V 1	22	240.3	2883	260	321	277	238	310	237	214	194	191	221	184	213	
V 2			263	307	290	240	308	238	219	189	223	226	187	216		
V 1	20	168.7	2025	192	228	195	165	218	165	144	121	153	167	121	141	
V 2			183	245	210	164	222	170	137	118	141	180	123	146		
V 1	18	94.1	1130	108	171	137	121	129	99	76	72	63	121	69	85	
V 2			85	134	114	84	86	69	58	59	85	102	59	73		
V 1	16	63.1	757	61	122	92	71	68	58	43	32	52	65	36	50	
V 2			62	118	95	74	73	57	42	38	50	71	39	45		
V 1	14	22.1	265	31	67	51	37	30	23	15	13	17	34	17	22	
V 2			16	37	26	17	13	9	7	6	6	19	8	9		
V 1	12	3.4	41	8	35	18	4	5	1	1	0	0	4	1	4	
V 1 =	1st attempt															
V 2 =	2nd attempt															
Check settings with field samples.														© LEHNER		

7 Appendix

Bellmix Mulchgrass 600

Time open:

Stopwatch is activated on actuation of slide and slide closes on expiry of period!!

Slice	Ø per hose	g/min	Hose number					9	10	11	12
			1	2	3	4	5				
V 1	38	169,1	2030	170	167	166	161	172	164	174	171
V 2				181	163	176	174	175	171	184	173
V 1	36	169,0	2028	171	172	179	174	176	176	176	172
V 2				174	170	182	146	163	176	179	179
V 1	34	168,9	2027	172	173	174	174	161	172	177	167
V 2				172	174	190	129	168	182	184	166
V 1	32	152,0	1824	172	165	180	170	166	161	164	177
V 2				178	69	105	169	143	155	164	168
V 1	30	108,2	1299	164	8	95	111	79	128	124	94
V 2				154	24	159	61	95	130	138	162
V 1	28	71,3	856	84	20	117	73	4	74	77	100
V 2				93	17	108	39	90	98	79	66
V 1	26	40,3	484	43	12	26	30	50	48	52	20
V 2				54	17	17	32	52	50	48	40
V 1	24	20,5	247	5	23	5	29	31	27	16	9
V 2				30	7	8	8	29	25	18	20
V 1	22	10,2	122	12	4	4	2	16	15	17	7
V 2				15	5	6	4	14	18	18	3
V 1	20	4,8	58	8	3	1	2	4	7	7	1
V 2				8	1	1	2	7	6	5	7
V 1	18	2,4	29	2	2	1	1	4	1	4	2
V 2				4	1	1	1	3	3	3	2
V 1	16	0,9	11	0	1	1	1	2	1	2	1
V 2				1	0	0	1	2	1	1	0
V 1 =	1st attempt										
V 2 =	2nd attempt										
Check settings with field samples.											
The flow properties of grass seed are greatly affected by external factors such as moisture content and humidity.											
© LEHNER											

7 Appendix

Bellmix Mulchgrass 500

Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!

The flow properties of grass seed are greatly affected by external factors such as moisture content and humidity.

© LEHNER

7 Appendix


Bellmix Mulchgrass 300		Stopwatch is activated on actuation of slide and slide closes on expiry of period!!!															
Time open:		g/min	Ø per hose	Ø overall	1	2	3	4	5	6	7	8	9	10	11	12	
V 1	38	168.0	2017	174	168	174	169	119	169	175	170	168	165	165	169		
V 2				172	169	172	174	139	164	179	179	168	179	174	175		
V 1	36	176.8	2122	180	184	182	187	137	168	177	185	180	182	176	180		
V 2				177	174	171	168	181	178	181	183	181	176	180	176		
V 1	34	178.8	2145	177	174	171	168	181	178	185	176	181	176	180	176		
V 2				190	174	173	177	180	181	187	178	190	180	179	178		
V 1	32	174.1	2089	174	183	177	169	158	173	176	181	172	186	177	173		
V 2				167	181	179	162	174	171	174	168	182	174	185	162		
V 1	30	155.2	1862	168	172	163	117	156	160	164	161	153	174	171	163		
V 2				148	190	60	84	162	161	161	167	179	173	169	148		
V 1	28	94.0	1128	91	38	23	107	113	112	118	143	127	118	107	87		
V 2				115	92	58	106	115	86	104	46	154	8	77	111		
V 1	26	49.8	597	47	43	26	45	27	74	51	75	105	3	49	50		
V 2				52	16	21	15	41	64	72	69	111	21	61	56		
V 1	24	18.0	216	12	3	9	3	7	18	27	6	9	19	23	19		
V 2				27	8	8	4	13	33	35	31	29	32	26	31		
V 1	22	8.7	105	8	4	4	3	13	12	14	15	10	11	16	15		
V 2				5	3	1	2	9	4	11	7	14	4	13	11		
V 1	20	6.3	76	3	1	1	11	8	10	6	11	2	9	9	9		
V 2				4	2	1	2	11	9	9	9	9	8	7	7		
V 1	18	2.3	28	1	0	1	0	3	4	5	2	5	2	2	3		
V 2				0	1	0	3	5	5	2	3	3	2	4	4		
V 1 =	1st attempt																
V 2 =	2nd attempt																
Check settings with field samples.																	
The flow properties of grass seed are greatly affected by external factors such as moisture content and humidity.																	© LEHNER

7 Appendix

7.6 Slide settings

Version with 12 hoses

Number of opened hoses in position A: 12 (Exception: slide 81035)




Number of opened hoses in position B:	Opened hose												Slide number
	1	2	3	4	5	6	7	8	9	10	11	12	
2													81006
4													81003
6													80986
6													81007
6													81008
Position A: 6													81035
8													80987
10													81001

= Hose opened

7 Appendix

Version with 6 Hoses

Number of opened hoses in position A: 6



Number of opened hoses in position B:	Opened hose						Slide number
	1	2	3	4	5	6	
1							
2							81004
4							80955

= Hose opened

LEHNER Maschinenbau GmbH
Häuslesäcker 14
D-89198 Westerstetten/Germany
Tel.: (+49) 07348 95 96 22
Fax: (+49) 07348 95 96 40
www.lehner.eu
info@lehner.eu

English